To create installation disk for micro das or das 3 using Winda 2.10

Make a c:\bin folder
Copy disk 1 and disk 2 to c:\bin
Copy the setup files to the normal c:\dljsetup\car_2
Open dljsetup and car_2
Open the setup files and make any adjustments
Re-name car_2 location to match the installation, remove all other driver names
Close dlj setup
Edit the das.inf file and change the last lines to install the correct setup files
Delete the last line if the data file is not needed
Save and exit.
Remove any pre-existing setup files from c:\bin\disk2\car-2
Copy new setup files to c:\bin\disk2\car_2
Edit the car.cfg file to match the new setup table name
Copy the c:\dljsetup.ini file and overwrite the c:\bin\disk2\set_dljs\dljsetup.ini
(this ensures that the correct driver name is used.

To add files to either dlj or wintaxj use the folders set_wtx or set_dljs

Copy all file from disk 1 & 2 to a new folder and test installation.

Make disks if OK